DEPARTURE

The normal taxi-route procedure is clockwise taxiing where parallel taxiways are established.
Reference see AD 2 ESSA 2.20 Taxi Procedures.
Pilots will receive instruction to change frequency between 121.705, 121.930 and 121.980 when crossing the area boundaries of Arlanda Ground. Depending on RWY's in use the areas of responsibility of Arlanda Ground vary.
ACFT will receive first GND frequency to contact from Clearance Delivery.

Freq: 121,930

Freq: 121,705

Freq: 121,980

Annual Change + 0.2°E
VAR 6° E 2020

RFF Station
DEICING G
DEICING S
DEICING R
CONSTRUCTION AREA
Sky City
Terminal 5
Terminal 4
Terminal 3
Terminal 2
Pier A
Pier B
Pier F
Stand 1-7
Stand 12-20
Stand 53-62
Stand 63-65
Stand 66-68 102-112
Apron TWY D
Apron TWY M
Hangar
Cargo Terminals
Jumbo Hostel
BASINS
MAX wingspan 24 m

LEGEND
- Asphalt
- Buildings
- Water surface
- TWY bridge
- Comunication borders
- Manoeuvring area